

# DMXCHANNELS

## 12 channel definition table

CHs	Function	Description
1	Dimmer	W and Y linear dimmer (0-100%)
2	Strobe	W, Y strobe (0-100%)
3	Effects	0-25 0
		26-35 Movement effect1.
		.....
		126-135 Jump effect6.
		136-150 Gradually move1.
		.....
		236-245 Gradually move6.
		246-255 Sound
0-25 0	Slow-fast (0-100%)	
4	Speed	
5	W1 dimmer	W1 linear dimmer (0-100%)
6	Y1 dimmer	W1 linear dimmer (0-100%)
7	W2 dimmer	W2 linear dimmer (0-100%)
8	Y2 dimmer	W2 linear dimmer (0-100%)
9	W3 dimmer	W3 linear dimmer (0-100%)
10	Y3 dimmer	W2 linear dimmer (0-100%)
11	W4 dimmer	W4 linear dimmer (0-100%)
12	Y4 dimmer	W2 linear dimmer (0-100%)

## 6 channel definition table

CHs	Function	Description
1	Dimmer	W, Y linear dimmer (0-100%)
2	Strobe	W, Y strobe (0-100%)
3	Auto effect	0-25:No 26-35:Jump1 126-135:Jump11 136-145:Linear dimming run1 236-245: Linear dimming run11, 246-255: Sound
4	Speed	From slow to fast (0-100%)
5	W dimmer	W linear dimmer (0-100%)
6	Y dimmer	Y linear dimmer (0-100%)

## 2 channel definition table

CHs	Function	Description
1	W dimmer	W linear dimmer (0-100%)
2	Y dimmer	Y linear dimmer (0-100%)