



## 1. KEYS INSTRUCTION



DIGITAL SHOW FUNCTION FORM ( Press button ENTER to save the setting after changing the function )

## 2. DMX512 CHANNELS

Channels	Function	Function introduction
CH 1	Dimmer	R、G、B、W , Dimmer, linear dimming, from dark to bright
CH 2	Strobe	R、G、B、W, Strobe, Strobe speed, from slow to fast;
CH 3	Function option	0-5: 6-40: 41-80: 81-120: 121-160: 161-200: 201-240: 241-255:
CH 4	Function speed	Function speed, from slow to fast;
CH 5	R Dimmer	R Dimmer, linear dimming, from dark to bright
CH 6	G Dimmer	G Dimmer, linear dimming, from dark to bright
CH 7	B Dimmer	B Dimmer, linear dimming, from dark to bright
CH 8	W Dimmer	W Dimmer, linear dimming, from dark to bright
CH 9	ZOOM	Beam angle from small to large
CH 10	CTO	
CH 11	Color changes	